

Chanza



Chanza Sobremesa

Bombillas **1xE14**
Material Pantalla **Textil**
Material Armazón **Metal**



Pantalla **Blanco**
Armazón **Cromo**
157671001



Pantalla **Beige**
Armazón **Cromo**
157671015



Pantalla **Gris**
Armazón **Cromo**
157671028



Chanza Colgante

Bombillas **1xE27**
Material Pantalla **Textil**
Material Armazón **Metal**



Pantalla **Blanco**
Armazón **Cromo**
157693001



Pantalla **Beige**
Armazón **Cromo**
157693015




Pantalla **Gris**
Armazón **Cromo**
157693028

Chanza



Chanza Colgante

Bombillas **2xE27**
Material Pantalla **Textil**
Material Armazón **Metal**



Pantalla **Blanco**
Armazón **Cromo**
157694001



Pantalla **Beige**
Armazón **Cromo**
157694015




Pantalla **Gris**
Armazón **Cromo**
157694028



Chanza Colgante

Bombillas **3xE27**
Material Pantalla **Textil**
Material Armazón **Metal**



Pantalla **Blanco**
Armazón **Cromo**
157695001



Pantalla **Beige**
Armazón **Cromo**
157695015



Pantalla **Gris**
Armazón **Cromo**
157695028